

48/1951 Unfinished Wood Birdhouse Kits

Nail together on work surface under adult supervision.

1. Assemble and nail front and back to sides as in diagram A. Nail slowly so wood does not split.
2. Nail the base and roof pieces on as shown below. The base should stick out from the front and the top roof hangs out more in front than the back.
3. Finish with roof cap.
4. Glue small block of wood below opening.
5. Screw hanger in center of roof cap.

Diagram A

